



WATCH YOUR TV ON YOUR MOBILE PHONE OR TABLET. REALLY.

Extend your living room TV experience to your tablet or smartphone with SlingPlayer® software. With a Slingbox* at home and SlingPlayer on your compatible device, enjoy live or recorded TV over a 3G, 4G or Wi-Fi connection. If you like TV, it's hard not to smile when you take control of your TV and DVR right from your tablet or smartphone. Flip through channels with the virtual remote control. Pause, fast forward, rewind and even schedule DVR recordings. Never miss another show or game — whether you're in the backyard, out to lunch or on the other side of the world. It's your TV. Don't let it be trapped in your living room.

ANYTIME, ANYWHERE

Waiting for a flight? Kids getting bored? Need a TV fix? Keep yourself, your family and your friends entertained anytime, anywhere.

WATCH YOUR TV

Tune in to your favorite TV shows—sports, special events or any live programming. Catch up on recorded shows or listen to music channels.

TAKE CONTROL

Easily change your TV channels, navigate program guides and schedule recordings on your DVR.

GETTING STARTED WITH SLINGPLAYER IS SIMPLE

Purchase and download SlingPlayer for your mobile device. Compatible devices include:

- Android phones and tablets
- iPhone, iPod touch and iPad
- Windows Phone

Connect to your compatible Slingbox*. Experience your TV over 3G, 4G or Wi-Fi.

* SlingPlayer requires the use of an internet-connected Slingbox SOLO or Slingbox PRO-HD. When used with an Android tablet, iPad or a Windows Phone device, only Slingbox SOLO and Slingbox PRO-HD are supported. Check with your mobile service provider if a data plan is required or if additional fees apply.

COMPATABILITY

SLINGPLAYER FOR MOBILE DEVICES

iPHONE, IPOD TOUCH and IPAD

- All iPhone and iPod touch* devices with iOS 4.1 or above
- All iPad devices with iOS 4.2 or above

ANDROID

- All Android phone devices running Android 1.6 or above
- All Android tablet devices running Android 3.0 or above

WINDOWS PHONE

- All Windows Phone devices

PALM

- Centro
- Treo 700p
- Treo 755p

BLACKBERRY

- BlackBerry Bold 9700 from AT&T
- BlackBerry Bold 9700 from T-Mobile
- BlackBerry Bold 9000 from AT&T
- BlackBerry Bold 8820 from AT&T*
- BlackBerry Curve 8900 from AT&T*
- BlackBerry Curve 8900 from T-Mobile*
- BlackBerry Curve 8520 from AT&T*
- BlackBerry Curve 8520 from T-Mobile*
- BlackBerry Curve 8350i from Sprint*
- BlackBerry Curve 8320 from AT&T*
- BlackBerry Curve 8320 from T-Mobile*
- BlackBerry Pearl Flip 8820 from T-Mobile*
- BlackBerry Pearl 8120 from AT&T*
- BlackBerry Pearl 8120 from T-Mobile*

SYMBIAN

- Nokia N96
- Nokia N95 8GB
- Nokia N95
- Nokia N85
- Nokia N82*
- Nokia N79
- Nokia N75
- Nokia E75
- Nokia E72
- Nokia E71x
- Nokia E71
- Nokia E65
- Nokia E63
- Nokia E52
- Nokia 6790 Surge
- Sony Ericsson P1i*
- Sony Ericsson P990i*
- Sony Ericsson G900
- Sony Ericsson W960i*

* Denotes devices that connect to the internet via Wi-Fi only.

For more information, please contact our Sales Team at:
www.slingmedia.com/go/contact.

Visit www.slingmedia.com/mobile for the latest information on SlingPlayer for Mobile Devices.

Copyright © 2012 Sling Media, Inc. Sling, Sling Media, Slingbox, SlingLoaded, SlingGuide and SlingPlayer are the trademarks or registered trademarks of Sling Media, Inc. Other products and companies mentioned are the trademarks of their respective owners and not of Sling Media, Inc.

Sling Media, Inc. is an EchoStar company.